



Instruction & Operation Manual



STEAM HUMIDIFIER ElectroVap[®] Series RTH-HC

ELECTROVAP® RTH-HC

Contents

| | | |
|----------|--|----|
| 1. | SAFETY INSTRUCTIONS | 3 |
| 1.1. | INTRODUCTION | 3 |
| 1.2. | REMARKS IMPORTANT es | 4 |
| 1.3. | DECLARATION OF CONFORMITY | 5 |
| 1.4. | RoHS DECLARATION | 5 |
| 2. | PRODUCT PRESENTATION | 6 |
| 2.1 | CHARACTERISTICS | 6 |
| 2.2 | Dimensions | 7 |
| 2.3 | HUMIDIFIER CONSTRUCTION | 8 |
| 2.4 | IMPORTANT instructions | 9 |
| 3. | INSTALLATION | 10 |
| 3.1 | PROCEDURE | 10 |
| 3.2 | water supply connection | 11 |
| 3.3 | STEAM OUTLET | 12 |
| 3.4 | CONDENSATE DRAIN WITH SIPHON | 13 |
| 3.5 | DRAIN HOSE CONNECTION | 13 |
| 3.6 | ELECTRICAL CONNECTIONS | 15 |
| 3.6.1 | Technical Data | 15 |
| 3.7 | ELECTRICAL WIRING | 17 |
| 3.8 | Option: REMOTE INFORMATION BOARD | 18 |
| 3.9 | ELECTRICAL WIRING DIAGRAMS | 19 |
| 3.10 | CONTROL SIGNAL CONNECTION | 25 |
| 3.10.1 | On/Off Control And Safety Contacts | 25 |
| 3.10.2 | Proportional control | 25 |
| 3.10.3 | RS485 connection | 26 |
| 3.10.4 | MODBUS RTU and BACNET MSTP Communication Parameters | 26 |
| 3.10.4.1 | Standardized Bacnet Protocol Implementation Sheet | 27 |
| 3.10.4.2 | MODBUS RTU & BACNET MSTP Communication Parameters | 27 |
| 3.10.4.3 | Communication Protocol for RS485 interface - MODBUS and BACNET | 27 |
| 3.11 | wiring diagrams | 30 |
| 3.12 | Water level sensor wiring | 33 |
| 4. | COMMISSIONING | 34 |
| 5. | SYSTEM MANAGEMENT | 35 |
| 5.1 | Information menu (read-only) | 35 |
| 5.2 | SETUP menu | 37 |
| 5.3 | control SYSTEM MENU | 38 |
| 5.4 | menu: HUMIDIFIER CONFIGURATION | 40 |
| 5.5 | MAINTENANCE ALERTS | 43 |
| 5.6 | DEFAULT MESSAGES | 44 |
| 6. | MAINTENANCE | 50 |
| 6.1 | STAINLESS STEEL TANK | 50 |
| 6.2 | DRAIN VALVE | 51 |
| 6.3 | WATER INLET VALVE | 52 |
| 6.4 | water level sensor | 52 |
| 7. | SPARE PARTS | 53 |
| 7.1 | STAINLESS STEEL cUVE | 53 |
| 7.2 | Water inlet solenoid valve | 54 |
| 7.3 | Water level sensor | 54 |
| 7.4 | Drain solenoid valve | 54 |
| 7.5 | Electrical part | 55 |

ELECTROVAP® RTH-HC






1. SAFETY INSTRUCTIONS

1.1. INTRODUCTION

You've recently purchased the ElectroVap® RTH-HC humidifier, and we hope you enjoy this product. Thank you for the trust you place in us. The safety instructions contained in this manual are intended for specialized, qualified personnel who are authorized to install, commission and maintain the unit.

To get the best results from your humidifier, we recommend :

- Read the instructions in this manual carefully;
- Keep this manual in a safe place for future reference;
- Please pass on this manual in the event of sale or transfer of the unit, to ensure that all relevant information is passed on;

| SAFETY WARNINGS AND SYMBOLS USED IN THIS MANUAL | |
|---|---|
|  | Danger! Caution. General safety instructions, violation of which could lead to malfunctions and/or personal injury and/or property damage. |
|  | Danger! High voltage. If high voltages are present inside the device or any of its components, failure to heed this warning may result in death or serious injury to the user. people and/or major equipment malfunctions. |
|  | Danger! High temperatures. Make sure that protective equipment is worn and keep a safe distance from the machine. between the device and any materials likely to be damaged by heat. |
|  | Electrostatic hazard. Device components may be subject to damage as they are highly sensitive to electrostatic discharge. |
|  | Möbius strip. Some parts of the device can be recycled. The user is responsible for their disposal. Follow the recycling recommendations adapted to the materials used in your area. |

- If the package is damaged, please make a claim to your carrier by registered letter with acknowledgement of receipt within 24 hours and make a declaration to your Devatec representative.
- Pictures, graphics and values are subject to change without notice.
- Keep these instructions in a safe place, and if you have any questions which are not answered in this manual, please do not hesitate to contact us or your Devatec representative.

Our team is ready to listen!

ELECTROVAP® RTH-HC

1.2. REMARKS IMPORTANT ES

| | |
|--------------------|--|
| GENERAL | <p>This manual is a translation of the original French version. It contains full details of installation, commissioning and maintenance of the ElectroVap® RTH-HC humidifier.</p> <p>Maintenance, service and repairs, as well as the study of the risks and dangers associated with these operations, must be carried out by qualified, competent and authorized personnel.</p> <p>Make sure that any risks or hazards, especially when working at height, are defined in advance by an authorized person.</p> <p>We also recommend installing a safety perimeter. Make sure the power supply is disconnected before carrying out maintenance.</p> <p>Please tighten all power cable terminals periodically.</p> |
| INTENDED USE | <p>The ElectroVap® RTH-HC humidifier manufactured by Devatec is designed exclusively for humidifying air in air handling units and rooms.</p> <p>The user undertakes to use the equipment in accordance with the safety rules set out in this documentation.</p> <p>Improper use may result in danger and serious damage to the user, third parties and equipment.</p> |
| STORAGE & HANDLING | <p>The unit must be stored in a dry, frost-proof place, protected from shocks and vibrations. Handling must be carried out by at least two people or by suitable lifting equipment.</p> |
| WATER | <p>Steam humidifiers can be used with potable, demineralized or softened water. It is absolutely forbidden to inject chemicals into the hydraulic system. Ensure that the water supply pressure does not exceed 8 bar. Always ensure that the installation complies with local standards.</p> |
| ELECTRICITY | <p>The user guarantees that the electrical installation work will be carried out by a qualified technician. It is the installer's responsibility to provide the correct cable cross-section and thermal-magnetic circuit breaker protection, in accordance with the regulations in force in the country of installation. Ensure that the humidifier is earthed with a suitable conductor.</p> |
| GUARANTEE | <p>Devatec warrants its units for 12 months from date of installation and 15 months from date of shipment; excluding wear parts, labor and the following wear parts: water supply solenoid valve, drain solenoid valve, heating resistor, contactor and solid state relay are warranted for 6 months.</p> <p>Devatec's liability shall be limited exclusively to the repair or replacement by Devatec of the part or product, excluding labor or other disassembly or installation costs. At its discretion, Devatec may also decide to refund the purchase price of the part or product. Failure to comply with the above recommendations, additional assembly and/or conversion using components other than those supplied with the device, or any other use other than that intended, will be considered as non-compliance with the prescriptions and will invalidate the warranty.</p> |
| RESPONSIBILITY | <p>Devatec accepts no liability for faulty installation or improper use of the equipment and its components.</p> <p>We strive to provide you with a manual that is as comprehensive as possible. However, conditions in the air handling industry are such that the information contained in this documentation may be subject to change without notice.</p> |

ELECTROVAP® RTH-HC

1.3. DECLARATION OF CONFORMITY

The devices, identified by serial numbers between 600 000 and 699 999, meet the requirements of the following European directives:

2014/30/EU

2014/35/EU

| | |
|-------------|--|
| DEVICE TYPE | Humidifier |
| MODEL NAME | RTH-HC |
| BUILDER | Devatec 185 Boulevard des Frères Rousseau 76550 Offranville - FRANCE |

We hereby declare that the equipment specified above conforms to the directives mentioned at the beginning of this declaration. This applies to units numbered 600 001 to 699 999.

FRAMBOT Jean-François

General Manager

05/01/2021



1.4. ROHS DECLARATION

Devatec,

Confirms that the ElectroVap® RTH-HC humidifier is manufactured in compliance with the following European regulations:

2011/65/EU (RoHS)

These regulations govern the use of mercury, cadmium, lead (in welding processes), chromium VI as well as PBB and PBDE after July 1, 2006.

MINFRAY Jean-Marie

R&D Engineer

05/01/2021



ELECTROVAP® RTH-HC

2. PRODUCT PRESENTATION

2.1 CHARACTERISTICS

The RTH-HC humidifier is an electric humidifier designed for air humidification in AHUs or rooms. Like all humidifiers in the range, it is compatible with our BlowerPack ventilation unit.

Standard delivery includes :

1. Steam humidifier
2. Technical documentation
3. 3 hose clamps per tank (2 for the steam hose and 1 for the drain hose) per tank




Fig. 2-1. Humidifier

ACCESSORIES (Not supplied)

- Stainless steel steam tubes
- ExpressPack®
- BlowerPack fan unit
- Steam and condensate hoses
- Duct or room humidity transmitter
- High-limit hygostat
- 3/4" FF stainless steel braided hose (with gaskets) for connection to the water network.
- Drain hose
- Remote Information Board
- Filling cup extension
- Transformateur 3x380-600V/2x115V
- Additional cooling kit
- Outdoor protective cabinet
- Mounting bracket
- Collecting Water Tank

ELECTROVAP® RTH-HC

2.2 DIMENSIONS




Fig. 2-2. Humidifier sizes

| | RTH-HC 5-50 | RTH-HC 60-100 |
|------------------------------------|-------------|---------------|
| Number of steam outputs | 1 | 2 |
| Dimension [mm] / [in] | | |
| A: Width | 686 / 27.01 | 1124 / 44.26 |
| B: Height | 770 / 30.32 | 770 / 30.32 |
| C: Depth | 343 / 13.51 | 350 / 13.78 |
| D: Cabinet height | 751 / 29.57 | 751 / 29.57 |
| E1: Steam outlet position | 360 / 14.18 | 360 / 14.18 |
| E2: Steam outlet position | 165 / 6.5 | 165 / 6.5 |
| E3: Distance between steam outlets | | 592 / 23.31 |
| G1: Drain position | 629 / 24.77 | 641 / 25.24 |
| G2: Drain position | 163 / 6.42 | 291 / 11.46 |
| H1: Water inlet position | 582 / 22.92 | 702 / 27.64 |
| H2: Water inlet position | 261 / 10.28 | 261 / 10.28 |
| I: Overflow diameter | 12 / 0.48 | 12 / 0.48 |
| J1: Overflow position | 642 / 25.28 | 732 / 28.82 |
| J2: Overflow position | 32 / 1.26 | 32 / 1.26 |
| K: Steam outlet diameter | 60 / 2.37 | 60 / 2.37 |
| Weight [kg] / [lb] | | |
| Operating weight | 75 / 166 | 140 / 309 |
| Packed weight | 45 / 100 | 70 / 155 |

ELECTROVAP® RTH-HC

2.3 HUMIDIFIER CONSTRUCTION




Fig. 2-3. Humidifier construction

| | | | |
|----|-----------------------------------|----|----------------------------|
| 1 | Steam hose (optional) | 12 | Water inlet solenoid valve |
| 2 | Filling cup | 13 | Drain hose connection |
| 3 | Display board | 14 | Overflow pipe |
| 4 | Main board | 15 | Drain valve |
| 5 | Contactor | 16 | Filling hose |
| 6 | Fuse holders | 17 | Tank |
| 7 | 3-relay board (optional) | 18 | Water level sensor |
| 8a | Transformer 2x115 / 2x12V S: 50VA | 19 | Immersion heater |
| 9 | ON / OFF switch | 20 | Pressure balancing |
| 10 | Power rail | 21 | Static relay |
| 11 | Identification label | 22 | Fan |

ELECTROVAP® RTH-HC

2.4 IMPORTANT INSTRUCTIONS

- Ambient temperature: between 5°C and 40 °C
- Ambient humidity : < 80% Relative humidity
- Back side panel: this component heats up during operation (up to 60°C). Make sure that the construction on which the device is to be mounted is not a heat-sensitive material.
- Wall mounting: Please ensure that the supporting material (pillar, wall, etc.) is able to withstand the device.
- Fixation: use a fastening system adapted to the support material.
- Carefully observe the below distances when installing your device.




Fig.2-4. *Mounting distances*



Please read and follow the safety information in the manual and the warning labels inside the humidifier before installation or maintenance.

Some steps can be dangerous.

Visit our website or contact our operators for technical assistance.

ELECTROVAP® RTH-HC

3. INSTALLATION

3.1 PROCEDURE

- Mark and drill where indicated (hole size depends on the plugs and support materials chosen).
- Put the dowels in the holes.
- Screw the top screws into the dowels (M6 recommended), leaving them protruding by about 10 mm/0.39in.
- Hang the unit on the top screws and align it vertically and horizontally using a spirit level.
- Tighten up all screws.




Fig. 3-1. Mounting hole location

| | RTH-HC 5 - 50 | RTH-HC 60 - 100 |
|----|------------------|--------------------|
| | [mm]/ [in] | |
| A | 640 / 25.2 | 1000 / 39.38 |
| A1 | 22 / 0.87 | 500 / 19.69 |
| A2 | | 61 / 2.41 |
| A3 | 201 / 7.92 | 160 / 6.3 |
| A4 | 301 / 11.86 | 310 / 12.21 |
| A5 | | 239 / 9.41 |

| | RTH-HC 5 - 50 | RTH-HC 60 - 100 |
|----|------------------|--------------------|
| | [mm]/ [in] | |
| B | 580 / 22.84 | 580 / 22.84 |
| B1 | 81 / 3.19 | 81 / 3.19 |
| B2 | 23 / 0.91 | 23 / 0.91 |
| B3 | 53 / 2.09 | 53 / 2.09 |

ELECTROVAP® RTH-HC


3.2 WATER SUPPLY CONNECTION

3.2.1 Recommendation

Our device is designed for use with the following types of water:

- ✓ Drinking water (in compliance with directive 98/83/EEC), TH (French degrees) between 0° fH and 40° fH with conductivity between 250 µS/cm and 1000 µS/cm
- ✓ Softened water, use possible only under certain conditions. Please contact us.
- ✓ Demineralized water, reverse osmosis water.

Fig. 3-2. Humidifier water supply



Demineralized water is corrosive, so use only pipes designed for this purpose (stainless steel, PVC).

Softened water: Not recommended, but possible. TH 12 °fH minimum.

A water analysis is recommended to determine sodium chloride levels.

If you have any questions about the quality and levels of your water, please do not hesitate to contact us.



Excessive concentrations of sodium chloride can cause foaming or scumming, which is detrimental to proper operation. It is therefore imperative to use **duplex softeners**. **Maximum chloride content: 80 mg/l**

3.2.2 Connection recommendations

Mains water pressure: Pressure must be stable and between 2 bar and 8 bar MAX.

Mains water temperature: < 40°C.

Please note that the water connection is made at the foot of the unit.

For ease of maintenance, the humidifier is fitted with a filter strainer that should be checked periodically. To facilitate maintenance, an isolation valve should be installed close to the humidifier.



RISK OF WATER OVERFLOW: we recommend installing a drip tray (optional) under the humidifier to prevent any risk of water overflow. This is essential if the unit is installed in a suspended ceiling or above a sensitive area (e.g. museum hall, exhibition room, laboratory, etc....). Equip the tank with a drainage system.

ELECTROVAP® RTH-HC

3.3 STEAM OUTLET

1. Preferably use a flexible steam hose resistant to a temperature of 100°C.

NB: when new pipes are installed, a smell of burnt plastic may appear when the steam humidifier is first turned on. This smell is normal and will diminish.

2. Steam hose selection :

| Model | RTH-HC 5 to 50 | RTH-HC 60 to 100 |
|-------------------------|-------------------|---------------------|
| Number of steam outlets | 1 | 2 |
| Steam outlet diameter | Ø 60 mm | Ø 60 mm |

3. The RTH-HC humidifiers can operate with a pressure (P) higher than the atmospheric pressure in the ducts, but under the following conditions:

- If P is less than 2157 Pa, i.e. a water column greater than 220mm, operation is standard.
- If P exceeds 2157 Pa, i.e. a water column greater than 220mm, options are available.
- If P is greater than 11,768 Pa, i.e. a water column greater than 1200 mm, please contact your sales representative.

4. To install the steam pipe in your environment, please follow the recommendations below and use the appropriate tangential clamps.

- Flexible steam hose, max. length 3 m.
- Rigid stainless steel or copper pipe, slightly larger diameter, grounded. The humidifier must be connected to the rigid steam pipe by a flexible steam pipe sleeve. The length of the pipe should not exceed 6 m, and it should be insulated.



Always slope in the same direction (upwards or downwards); the steam pipe must be free of bends and kinks to allow condensate to drain by gravity. Ensure that the steam pipe is free from leaks. Failure to comply with these instructions may result in serious malfunctions.

Steam pipe bending radius diameter :

- Ø 40 - 400mm minimum
- Ø 60 - 600mm minimum




Fig. A 3-4. Standard installation




Fig. B 3-4. Additional drip leg when steam is distributed under the humidifier

ELECTROVAP® RTH-HC

3.4 CONDENSATE DRAIN WITH SIPHON

POSITIVE PRESSURE SIPHON




Fig. A 3-5.

NEGATIVE PRESSURE SIPHON




Fig. B 3-5.

The condensate pipe must not be connected directly to the public sewage system.

$$H \text{ min. (mm)} = P \text{ (Pa)} / 10$$

with P = absolute pressure of the air handling unit or ventilation duct

3.5 DRAIN HOSE CONNECTION

The following drawing shows how to connect the drain hose.

Use a \varnothing 40 mm rubber drain hose with the 2 hose clamps supplied, heat-resistant (up to 100°C).

Connect the hose to the drain system. Regular replacement is recommended.

If you use a rigid pipe, it must be made of heat-resistant PVC (up to 100°C).

The drain hose must be free of obstructions.

We recommend that each humidifier has its own drain hose.

If possible, use a water collection tray with a lid (see photo below).

For manifolds installation and recommendations, see accessory documentation.




Fig. A 3-6. Installation example

ELECTROVAP® RTH-HC



Maintain a minimum downward slope (α) of 10° for the generator drain and overflow pipes, and for the general drain pipe.



The drain hose should be inserted about 8 cm into the collecting water tank (the hose must never come into contact with the waste water in the tank).




Fig. A 3-6. *Installation example*

ELECTROVAP® RTH-HC

3.6 ELECTRICAL CONNECTIONS

3.6.1 Technical Data

| Voltage (V) | RTH -HC | 3 | 5 | 7 | 8 | 10 | 15 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 |
|-------------|---------|-----|------|-----|------|------|------|------|------|------|------|------|------|------|-------|-------|
| 230V - 1 ph | kg/h | 2.5 | 5.7 | - | 8.3 | - | - | - | - | - | - | - | - | - | - | - |
| | kW (Pn) | 1.9 | 4.3 | - | 6.2 | - | - | - | - | - | - | - | - | - | - | - |
| | I (A) | 8.3 | 18.7 | - | 27.1 | - | - | - | - | - | - | - | - | - | - | - |
| 208V - 3 ph | kg/h | - | - | - | 6.2 | - | - | - | - | - | - | - | - | - | - | - |
| | kW (Pn) | - | - | - | 4.7 | - | - | - | - | - | - | - | - | - | - | - |
| | I (A) | - | - | - | 13.0 | - | - | - | - | - | - | - | - | - | - | - |
| 230V - 3 ph | kg/h | - | - | - | 7.6 | - | - | - | - | - | - | - | - | - | - | - |
| | kW (Pn) | - | - | - | 5.7 | - | - | - | - | - | - | - | - | - | - | - |
| | I (A) | - | - | - | 14.4 | - | - | - | - | - | - | - | - | - | - | - |
| 380V - 3 ph | kg/h | - | 4.7 | 6.9 | - | 10.8 | 15.6 | 21.5 | 26.4 | 38.1 | 46.8 | 53.7 | 62.5 | 76.3 | 85 | 93.7 |
| | kW (Pn) | - | 3.6 | 5.2 | - | 8.1 | 11.7 | 16.2 | 19.8 | 28.7 | 35.2 | 40.4 | 47.0 | 57.3 | 63.9 | 70.4 |
| | I (A) | - | 5.5 | 7.9 | - | 12.4 | 18 | 24.8 | 30.3 | 43.9 | 53.9 | 61.8 | 71.9 | 87.7 | 97.8 | 107.8 |
| 400V - 3 ph | kg/h | - | 5.3 | 7.6 | - | 11.9 | 17.3 | 23.9 | 29.2 | 42.2 | 51.9 | 58.5 | 69.2 | 84.5 | 94.2 | 103.8 |
| | kW (Pn) | - | 4.0 | 5.7 | - | 9.0 | 13.0 | 17.9 | 22.0 | 31.8 | 39 | 44.0 | 52.0 | 63.5 | 70.8 | 78.1 |
| | I (A) | - | 5.8 | 8.4 | - | 13.0 | 18.9 | 26.1 | 31.9 | 46.2 | 56.7 | 63.9 | 75.6 | 92.3 | 102.9 | 113.4 |
| 415V - 3 ph | kg/h | - | 5.7 | 8.2 | - | 12.8 | 18.6 | 25.7 | 31.5 | 45.5 | 55.9 | 64.1 | 74.5 | 91.0 | 101.3 | 111.7 |
| | kW (Pn) | - | 4.3 | 6.2 | - | 9.7 | 14.0 | 19.3 | 23.7 | 34.2 | 42.0 | 48.2 | 56.0 | 68.4 | 76.2 | 84.0 |
| | I (A) | - | 6.0 | 8.7 | - | 13.5 | 19.6 | 27.1 | 33.1 | 47.9 | 58.9 | 67.5 | 78.5 | 95.8 | 106.8 | 117.7 |
| 440V - 3 ph | kg/h | - | - | 6.4 | - | - | 14.4 | 20.8 | 28.9 | 35.2 | 43.3 | 49.7 | 57.7 | 70.5 | 78.5 | 86.6 |
| | kW (Pn) | - | - | 4.8 | - | - | 10.9 | 15.6 | 21.7 | 26.5 | 32.6 | 37.4 | 43.4 | 53.0 | 59.1 | 65.1 |
| | I (A) | - | - | 6.3 | - | - | 14.3 | 20.7 | 28.7 | 35.0 | 43.0 | 49.4 | 57.4 | 70.0 | 78.0 | 86.0 |
| 460V - 3 ph | kg/h | - | - | 7.0 | - | - | 15.8 | 22.7 | 31.6 | 38.5 | 47.3 | 54.3 | 63.1 | 77.0 | 85.9 | 94.7 |
| | kW (Pn) | - | - | 5.2 | - | - | 11.9 | 17.1 | 23.7 | 29 | 35.6 | 40.8 | 47.4 | 57.9 | 64.5 | 71.2 |
| | I (A) | - | - | 6.6 | - | - | 15.0 | 21.6 | 30.0 | 36.6 | 45.0 | 51.6 | 60.0 | 73.2 | 81.6 | 90.0 |
| 480V - 3 ph | kg/h | - | - | 7.6 | - | - | 17.2 | 24.8 | 34.4 | 41.9 | 51.5 | 59.1 | 68.7 | 83.9 | 93.5 | 103.1 |
| | kW (Pn) | - | - | 5.7 | - | - | 12.9 | 18.6 | 25.8 | 31.5 | 38.7 | 44.5 | 51.7 | 63.1 | 70.3 | 77.5 |
| | I (A) | - | - | 6.9 | - | - | 15.6 | 22.6 | 31.3 | 38.2 | 46.9 | 53.8 | 62.6 | 76.4 | 85.1 | 93.9 |
| 575V - 3 ph | kg/h | - | - | 7.0 | - | - | 15.8 | 22.8 | 31.6 | 38.6 | 47.4 | 54.4 | 63.2 | 77.1 | 86.0 | 94.8 |
| | kW (np) | - | - | 5.2 | - | - | 11.9 | 17.1 | 23.8 | 29.0 | 35.6 | 40.9 | 47.5 | 58.0 | 64.6 | 71.3 |
| | I (A) | - | - | 5.3 | - | - | 12.0 | 17.3 | 24.0 | 29.3 | 36.0 | 41.3 | 48.0 | 58.6 | 65.4 | 72.1 |
| 600V - 3 ph | kg/h | - | - | 7.6 | - | - | 17.2 | 24.8 | 34.4 | 42 | 51.6 | 59.2 | 68.8 | 84.8 | 93.6 | 103.2 |
| | kW (np) | - | - | 5.7 | - | - | 12.9 | 18.6 | 25.9 | 31.6 | 38.8 | 44.5 | 51.7 | 63.2 | 70.4 | 77.6 |
| | I (A) | - | - | 5.5 | - | - | 12.5 | 18.1 | 25.1 | 30.6 | 37.6 | 43.1 | 50.1 | 61.2 | 68.2 | 75.2 |

ELECTROVAP® RTH-HC




Fig. A 3-7. Electrical connections



All wires must enter the unit through a cable gland (not supplied).



Device switch: when the device is switched off, there is still voltage inside. **Electric shock can be fatal, so the power switch must be turned off.**



Connections to terminals: L1, L2, L3 (35mm²), and L, N (16mm²) must be made with copper wires.



All work on electrical parts must be carried out by qualified and authorized personnel. In addition, before making any electrical connections, check that your installation has been determined using the values in the table on page 21.



Electronic components are sensitive to electrostatic discharge. Observe local regulations regarding electrical connections.


ELECTROVAP® RTH-HC

3.7 ELECTRICAL WIRING


Up [V] = POWER VOLTAGE

Uc [V] = CONTROL VOLTAGE


Up(V) = 1x200 - 230Vac (50-60Hz)




Up(V) = 3x200 - 230Vac (50-60Hz)



Up(V) = 3x380 - 420Vac (50-60Hz) with neutral




Up(V) = 3x380 - 690Vac (50-60Hz)
Uc (V) = 1x200 - 230Vac (50-60Hz)



ELECTROVAP® RTH-HC


$U_p(V) = 3 \times 380-690V_{ac}$ (50-60Hz)

With **OPTION**: Transformer: drv: 2x115V




3.8 OPTION: REMOTE INFORMATION BOARD

A NO or NC contact can be selected by connecting as shown below (e.g. connection to 30 and 31 = NO contact).



Check jumper S7, S8, S9.

Control of terminal blocks :





- X20 (30-31-32) : Dry contact for tank maintenance return.
- X21 (33-34-35) : Dry contact for general fault return.
- X22 (36-37-38): Dry contact for steam generation.

ELECTROVAP® RTH-HC



3.9 ELECTRICAL WIRING DIAGRAMS

Up[V] - 1x200-240V 50-60Hz








ELECTROVAP® RTH-HC

RTH-HC 8-18, Up[V] - 3x200-240V 50-60Hz





G-1 CABINET GROUND






ELECTROVAP® RTH-HC


RTH-HC 5-30, Up[V] - 3x380-690V 50-60Hz



G-1 CABINET GROUND





On/Off Switch (1)






ELECTROVAP® RTH-HC


RTH-HC 60-70, Up[V] - 3x380-690V 50-60Hz



G-1 CABINET GROUND





On/Off Switch




ELECTROVAP® RTH-HC

RTH-HC 80-100, Up[V] - 3x380-690V 50-60Hz



G-1 CABINET GROUND




ELECTROVAP® RTH-HC

3.10 CONTROL SIGNAL CONNECTION


3.10.1 ON/OFF Control And Safety Contacts

The control must be connected using flexible shielded cable, maximum 0.75mm². This cable must not be routed with a power cable. To activate the control type, see chapter "HUMIDIFIER CONFIGURATION".



Configuration without safety contact:

⇒ Shunt between terminals 1 and 2



Configuration with safety contact(s):


⇒ Detector(s) to be connected in series to terminals 1 and 2

Example: Door open detection thermostat


CTRL SIGNAL TYPE

1 STEP (ON/OFF)

3.10.2 PROPORTIONAL CONTROL



Proportional humidity controller



Humidity sensor with 24VDC (18,19 ,20) or 24 VAC (33,19,20) power supply

ELECTROVAP® RTH-HC



3.10.3 RS485 CONNECTION

RS485 is connected to connector J2 :

- Terminal 1: Data -
- Terminal 2: Data +
- Terminal 3: GND

Switch SW1 is used to activate or deactivate the line resistor. Depending on requirements, these resistors can be activated or deactivated (see diagram).

Fig. B 3-9.



3.10.4 MODBUS RTU and BACNET MSTP Communication Parameters

| | Modbus RTU | Bacnet MSTP |
|--|---|-------------|
| Communication speed | 2400 / 4800 / 7200 / 9600 (default) / 14400 / 19200 / 28800 / 38400 / 57600 / 115200 / 230400 | |
| Packet size | 8 bits | |
| Parity bit | No | |
| Stop bit | 2 | 1 |
| Response time Before the timeout | 5000ms (5sec) | |
| Time between 2 requests (After receiving a reply) | Min. 100ms | Standard |

ELECTROVAP® RTH-HC

3.10.4.1 Standardized Bacnet Protocol Implementation Sheet

BACnet Protocol Implementation Conformance Statement

Date: 18/10/2022

Vendor Name: Armstrong International

Product Name: Armstrong Motherboard

Product Model Number: see plate.

Application Software Version: 1 Firmware Revision: 1 BACnet Protocol Revision: 19

Product Description: Mother board with integrated automate functions.

BACnet Standardized Device Profiles Supported (Annex L): BACnet Application Specific Controller (B-ASC)

BACnet Interoperability Building Blocks Supported (Annex K): Minimal required by B-ASC devices

Segmentation Capability: No segmentation

Standard Object Types Supported: Available objects are listed in the object table; each object has the minimal requirement by the standard.

The main device objectID is by default 0x02000000 + vendor ID x 1000 + ThisStationAddress, can be set in menu.

Data Link Layer Options: MS/TP master (Clause 9), baud rate(s): 9600,38400, and others (see table above).

Device Address Binding: No

Networking Options: none

Character Sets Supported: ISO 10646 (UTF-8)

For further information, please contact your dealer.

3.10.4.2 MODBUS RTU & BACNET MSTP Communication Parameters

| | Modbus RTU | Bacnet MSTP |
|--|---|-------------|
| Communication speed | 2400 / 4800 / 7200 / 9600 (default) / 14400 / 19200 / 28800 / 38400 / 57600 / 115200 / 230400 | |
| Packet size | 8 bits | |
| Parity bit | No | |
| Stop bit | 2 | 1 |
| Response time Before the timeout | 5000ms (5sec) | |
| Time between 2 requests (After receiving a reply) | Min. 100ms | Standard |

3.10.4.3 Communication Protocol for RS485 INTERFACE - MODBUS and BACNET

| Modbus Register Address | Bacnet Object Class / instance # / ID (hex) | | | Description | Value |
|-------------------------|---|------------|----------|---------------|-------------------------------|
| | Class | Instance # | ID (hex) | | |
| 10001 | BI | 0 | 00C00000 | inlet valve | 1 = Filling -- 0 = No filling |
| 10002 | BI | 1 | 00C00001 | drain valve | 1 = drain -- 0 = no drain |
| 10003 | BI | 2 | 00C00002 | contactor K1 | 1 = ON -- 0 = OFF |
| 10004 | BI | 3 | 00C00003 | contactor K3 | 1 = ON -- 0 = OFF |
| 10005 | BI | 4 | 00C00004 | Blower pack | 1 = ON -- 0 = OFF |
| 10006 | BI | 5 | 00C00005 | Service relay | 1 = ON -- 0 = OFF |

ELECTROVAP® RTH-HC


| | | | | | |
|-------|----|----|----------|-------------------------------------|--|
| 10007 | BI | 6 | 00C00006 | Alarm relay | 1 = ON -- 0 = OFF |
| 10008 | BI | 7 | 00C00007 | On/off Relay | 1 = ON -- 0 = OFF |
| 10009 | BI | 8 | 00C00008 | High limite sw | 1: detected -- 0: not detected |
| 10010 | BI | 9 | 00C00009 | Alarm A1 state | 1 = ON -- 0 = OFF |
| 10011 | BI | 10 | 00C0000A | Alarm A2 state | 1 = ON -- 0 = OFF |
| 10012 | BI | 11 | 00C0000B | Alarm A3 state | 1 = ON -- 0 = OFF |
| 10013 | BI | 12 | 00C0000C | Alarm A4 state | 1 = ON -- 0 = OFF |
| 10014 | BI | 13 | 00C0000D | Alarm A5 state | 1 = ON -- 0 = OFF |
| 10015 | BI | 14 | 00C0000E | Alarm A6 state | 1 = ON -- 0 = OFF |
| 10016 | BI | 15 | 00C0000F | Alarm A7 state | 1 = ON -- 0 = OFF |
| 10017 | BI | 16 | 00C00010 | Alarm A8 state | 1 = ON -- 0 = OFF |
| 10018 | BI | 17 | 00C00011 | Alarm A9 state | 1 = ON -- 0 = OFF |
| 10019 | BI | 18 | 00C00012 | Alarm A10 state | 1 = ON -- 0 = OFF |
| 10020 | BI | 19 | 00C00013 | Rh sensor error | 1 = ON -- 0 = OFF |
| 1 | BO | 0 | 01000000 | On/Off BMS command | 1 = ON: start required / 0 = Off: device off |
| 2 | BV | 1 | 01400001 | EOS drain statue | 1 = on / 0 = off |
| | | | | | |
| 30001 | AI | 0 | 00000000 | Type unit | 4: RTH-HC 5: RTH-LC 6: ERS-HC 7: ERS LC |
| 30002 | AI | 1 | 00000001 | Reg version | 1 |
| 30003 | AI | 2 | 00000002 | Demand | (%) |
| 30004 | AI | 3 | 00000003 | Steam output | 10 x (Kg/hr) |
| 30005 | AI | 4 | 00000004 | Run status | 1: Idle 2: Preheat cycle 3: Steam production 4 : Manual drain 5: Ready for use 6: Maintenance due 7: Fault 8: Aquastat on |
| 30006 | AI | 5 | 00000005 | Estimated time to service | (hours) |
| 30007 | AI | 6 | 00000006 | Production since last service (MSB) | (Kg) |
| 30008 | AI | 7 | 00000007 | Production since last service (LSB) | (Kg) |
| 30009 | AI | 8 | 00000008 | Total production (MSB) | (Kg) |
| 30010 | AI | 9 | 00000009 | Total production (LSB) | (Kg) |
| 30011 | AI | 10 | 0000000A | Total run time (MSB) | (Hours) |
| 30012 | AI | 11 | 0000000B | Total run time (LSB) | (Hours) |
| 30013 | AI | 12 | 0000000C | Remaining idle time to EOS drain | (Hours) |
| 30014 | AI | 13 | 0000000D | Control signal value | 10 x V or 10 x mA or % of |
| 30015 | AI | 14 | 0000000E | Temperature tank 1 | (°C) |
| 30016 | AI | 15 | 0000000F | Temperature tank 2 | (°C) |

ELECTROVAP® RTH-HC

| | | | | | |
|-------|----|----|----------|------------------------------------|--|
| 30017 | AI | 16 | 00000010 | Alarm A2 counter | A2 alarm counter |
| 30018 | AI | 17 | 00000011 | Alarm A3 counter | A3 alarm counter |
| 30019 | AI | 18 | 00000012 | Alarm A6 counter | A6 alarm counter |
| 30020 | AI | 19 | 00000013 | Alarm A7 counter | alarm counter A7 |
| 30021 | AI | 20 | 00000014 | Alarm A8 counter | alarm counter A8 |
| 30022 | AI | 21 | 00000015 | Partial drain timer | 10 x (s) |
| 30023 | AI | 22 | 00000016 | PWM main supply | trigger value |
| 30024 | AI | 23 | 00000017 | PWM counter | meter |
| 30026 | AI | 25 | 00000019 | Max production capability | |
| 30027 | AI | 26 | 0000001A | Number of tank | 1 or 2 |
| 30028 | AI | 27 | 0000001B | Unit type ID | unit type code |
| 30029 | AI | 28 | 0000001C | Unit voltage type | unit voltage code |
| 30030 | AI | 29 | 0000001D | Water level status | level detected from 0 to 3 |
| 30031 | AI | 30 | 0000001E | Power consumed | (kW) |
| 30032 | AI | 31 | 0000001F | Max power rating | (kW) |
| | | | | | |
| 40004 | AO | 3 | 00000003 | Digital Rh value or digital demand | (%) minimum = 1 and maximum = 100 |
| 40005 | AV | 4 | 00800004 | Rh set point | (%) minimum = 1 and maximum = 100 |
| 40006 | AV | 5 | 00800005 | EOS drain timer | (Hour) min = 1 and max = 120 |
| 40007 | AV | 6 | 00800006 | Service counter | (kg / 100) from 1 to 65000 |
| 40008 | AV | 7 | 00800007 | Aquastat status | 1: activate -- 2: deactivate |
| 40009 | AV | 8 | 00800008 | Aquastat setpoint | min 10 max 80 (°C) |
| 40010 | AV | 9 | 00800009 | Control signal type | 20 : OnOff 21: digital ctrl 22 : control digital 23 : 0-10V ctrl 24 : 1-5V ctrl 25 : 4-20mA ctrl 26 : 0-10V sensor 27 : 0-5V sensor |
| 40012 | AV | 11 | 0080000B | Control signal adjustment | (-128 %) min 123, max 133 |
| 40014 | AV | 13 | 0080000D | Temperature 1 adjustment | (-128 %) min 123, max 135 |
| 40015 | AV | 14 | 0080000E | Temperature 2 adjustment | (-128 %) min 123, max 136 |
| 40016 | AV | 15 | 0080000F | Proportional factor of PID | typ.: 20 min. 0 max. 50 |
| 40017 | AV | 16 | 00800010 | Integral factor PID | mini 0 maxi 50 |
| 40018 | AV | 17 | 00800011 | Derivative factor PID | mini 0 maxi 50 |

ELECTROVAP® RTH-HC

3.11 WIRING DIAGRAMS



Case 3:

| RTH | U [V] | H1 | H2 | H3 | H4 | H5 | H6 | H7 | H8 | H9 |
|-----|-------|------|------|------|------|------|------|------|------|------|
| 5 | 3x380 | 1.9K | 1.9K | 1.9K | . | . | . | . | . | . |
| | 3x400 | 277V | 277V | 277V | . | . | . | . | . | . |
| | 3x420 | | | | . | . | . | . | . | . |
| 7 | 3x380 | 1.9K | 1.9K | 1.9K | . | . | . | . | . | . |
| | 3x400 | 230V | 230V | 230V | . | . | . | . | . | . |
| | 3x420 | | | | . | . | . | . | . | . |
| | 3x440 | 1.9K | 1.9K | 1.9K | . | . | . | . | . | . |
| | 3x460 | 277V | 277V | 277V | . | . | . | . | . | . |
| | 3x480 | | | | . | . | . | . | . | . |
| 10 | 3x380 | 1.9K | 1.9K | 1.9K | . | . | . | . | . | . |
| | 3x400 | 346V | 346V | 346V | . | . | . | . | . | . |
| | 3x615 | | | | . | . | . | . | . | . |
| 15 | 3x380 | 4.3K | 4.3K | 4.3K | . | . | . | . | . | . |
| | 3x400 | 277V | 277V | 277V | . | . | . | . | . | . |
| | 3x420 | | | | . | . | . | . | . | . |
| 20 | 3x380 | 4.3K | 4.3K | 4.3K | . | . | . | . | . | . |
| | 3x400 | 230V | 230V | 230V | . | . | . | . | . | . |
| | 3x420 | | | | . | . | . | . | . | . |
| | 3x440 | 4.3K | 4.3K | 4.3K | . | . | . | . | . | . |
| | 3x460 | 277V | 277V | 277V | . | . | . | . | . | . |
| | 3x480 | | | | . | . | . | . | . | . |
| 30 | 3x380 | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | . | . | . |
| | 3x400 | 277V | 277V | 277V | 277V | 277V | 277V | . | . | . |
| | 3x420 | | | | | | | . | . | . |
| 40 | 3x380 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | . | . | . |
| | 3x400 | 230V | 230V | 230V | 230V | 230V | 230V | 1.9K | 1.9K | 1.9K |
| | 3x420 | | | | | | | 230V | 230V | 230V |
| | 3x440 | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | 1.9K | 1.9K | 1.9K |
| | 3x460 | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V |
| | 3x480 | | | | | | | | | |
| 50 | 3x380 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K |
| | 3x400 | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V |
| | 3x420 | | | | | | | | | |
| 50 | 3x380 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K |
| | 3x400 | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V |
| | 3x420 | | | | | | | | | |
| | 3x440 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K |
| | 3x460 | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V |
| | 3x480 | | | | | | | | | |
| 50 | 3x380 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K |
| | 3x400 | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V |
| | 3x615 | | | | | | | | | |
| 50 | 3x380 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K |
| | 3x400 | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V |
| | 3x690 | | | | | | | | | |


Case 1: Up[V] - 1x200-240V 50-60Hz

| RTH | U [V] | H1 | H2 | H3 |
|-----|-------|------|------|----|
| 3 | 1x208 | 1.9K | ■ | ■ |
| | 1x220 | 230V | | |
| | 1x230 | | | |
| 5 | 1x208 | 4.3K | | |
| | 1x220 | 230V | | |
| | 1x231 | | | |
| 8 | 1x208 | 4.3K | 1.9K | |
| | 1x220 | 230V | 230V | |
| | 1x232 | | | |

Case 2: Up[V] - 3x200-240V 50-60Hz

| RTH | U [V] | H1 | H2 | H3 | H4 | H5 | H6 | H7 | H8 | H9 |
|-----|-------|------|------|------|------|------|------|------|------|------|
| 8 | 3x208 | 1.9K | 1.9K | 1.9K | ■ | ■ | ■ | ■ | ■ | ■ |
| | 3x220 | 230V | 230V | 230V | | | | | | |
| | 3x230 | | | | | | | | | |
| 18 | 3x208 | 4.3K | 4.3K | 4.3K | ■ | ■ | ■ | ■ | ■ | ■ |
| | 3x220 | 230V | 230V | 230V | | | | | | |
| | 3x231 | | | | | | | | | |
| 25 | 3x208 | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | ■ | ■ | ■ |
| | 3x220 | 230V | 230V | 230V | 230V | 230V | 230V | | | |
| | 3x232 | | | | | | | | | |
| 36 | 3x208 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | ■ | ■ | ■ |
| | 3x220 | 230V | 230V | 230V | 230V | 230V | 230V | | | |
| | 3x233 | | | | | | | | | |
| 44 | 3x208 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K |
| | 3x220 | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V |
| | 3x234 | | | | | | | | | |

ELECTROVAP® RTH-HC



Case 2: Up[V] - 3x200-240V 50-60Hz

| RTH | U [V] | RIGHT TANK | | | | | | | | | LEFT TANK | | | | | | | | |
|-----|-------|------------|------|------|------|------|------|----|----|----|-----------|------|------|------|------|------|-----|-----|------|
| | | H1 | H2 | H3 | H4 | H5 | H6 | H7 | H8 | H9 | H12 | H23 | H34 | H45 | H56 | H67 | H78 | H89 | H910 |
| 51 | 3x208 | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | ■ | ■ | ■ | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | ■ | ■ | ■ |
| | 3x220 | 230V | 230V | 230V | 230V | 230V | 230V | | | | 230V | 230V | 230V | 230V | 230V | 230V | | | |
| | 3x230 | | | | | | | | | | | | | | | | | | |
| 62 | 3x208 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | ■ | ■ | ■ | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | ■ | ■ | ■ |
| | 3x220 | 230V | 230V | 230V | 230V | 230V | 230V | | | | 230V | 230V | 230V | 230V | 230V | 230V | | | |
| | 3x230 | | | | | | | | | | | | | | | | | | |

ELECTROVAP® RTH-HC

Case 3: Up[V] - 3x380-690V 50-60Hz

| RTH | U [V] | RIGHT TANK | | | | | | | | | LEFT TANK | | | | | | | | |
|-----|-------|------------|------|------|------|------|------|------|------|------|-----------|------|------|------|------|------|------|------|------|
| | | H1 | H2 | H3 | H4 | H5 | H6 | H7 | H8 | H9 | H1 | H2 | H3 | H4 | H5 | H6 | H7 | H8 | H9 |
| 60 | 3x380 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | • | • | • | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | • | • | • |
| | 3x400 | 230V | 230V | 230V | 277V | 277V | 277V | • | • | • | 230V | 230V | 230V | 277V | 277V | 277V | • | • | • |
| | 3x420 | | | | | | | | | | | | | | | | | | |
| | 3x440 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | • | • | • | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | • | • | • |
| 70 | 3x460 | 277V | 277V | 277V | 277V | 277V | 277V | • | • | • | 277V | 277V | 277V | 277V | 277V | 277V | • | • | • |
| | 3x480 | | | | | | | | | | | | | | | | | | |
| | 3x575 | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | • | • | • | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | • | • | • |
| | 3x600 | 346V | 346V | 346V | 346V | 346V | 346V | • | • | • | 346V | 346V | 346V | 346V | 346V | 346V | • | • | • |
| 80 | 3x615 | | | | | | | | | | | | | | | | | | |
| | 3x690 | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | • | • | • | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | • | • | • |
| | | 398V | 398V | 398V | 398V | 398V | 398V | • | • | • | 398V | 398V | 398V | 398V | 398V | 398V | • | • | • |
| | | | | | | | | | | | | | | | | | | | |
| 90 | 3x380 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | |
| | 3x400 | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | 230V | |
| | 3x420 | | | | | | | | | | | | | | | | | | |
| | 3x440 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K |
| 100 | 3x460 | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | 277V | |
| | 3x480 | | | | | | | | | | | | | | | | | | |
| | 3x575 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K |
| | 3x600 | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V | 346V |
| 100 | 3x615 | | | | | | | | | | | | | | | | | | |
| | 3x690 | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 4.3K | 1.9K | 1.9K | 1.9K | |
| | | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | 398V | |
| | | | | | | | | | | | | | | | | | | | |

ELECTROVAP® RTH-HC

3.12 WATER LEVEL SENSOR WIRING

- 49 : Reference (if electrode sensor)
- 50: High level
- 51: Intermediate level

Fig. C 3-12. FLOAT LEVEL SWITCH





Fig. D 3-12. (OPTION) ELECTRODE LEVEL SWITCH



4. COMMISSIONING



Before commissioning your appliance, please check that your installation complies with the manufacturer's technical specifications. Screw back all electrical power cable terminals.

Marker 1: Validation & change menu button

Marker 2: Scroll up menu

Marker 3: Scroll down menu

Marker 4: Manual drain button for maintenance

Marker 5: LED = Steam production indication

- Open the main water supply valve.
- Switch off the device (power and control voltages).
- Set I/O (on/off) switch to I.
- If the device requires a commissioning code, please note the serial number on the nameplate and contact your sales representative to obtain the code.




Fig. 4 Humidifier display

- Enter your three-digit code as follows:
Press one of the 1, 2, 3 buttons and the display shows 0XX, with the zero flashing, so you can change it by pressing 2 or 3.
Once you've reached the required digit, confirm it by pressing 1 and your second digit will flash.
Repeat the previous two operations to display the last two digits.


Very important: don't forget to validate the last digit.

- Enter water quality in the menu displayed.
- The machine is ready to meet any production demand.
- When steam is produced, the LED (5) lights up.

ELECTROVAP® RTH-HC

5. SYSTEM MANAGEMENT

5.1 INFORMATION MENU (READ-ONLY)




ELECTROVAP® RTH-HC

| | |
|---|---|
| STEAM DEMAND XXX % | Display of steam demand in %. |
| TANK TEMPERATURE XXX °C XXX °F | Water temperature (RTH 1 tank) |
| T: L XXX °C XXX °F R XXX °C XXX °F | Water temperature in both tanks (RTH 2 tanks). L: Left tank, R: Right tank |
| TIME REMAINING TO EOS XXXX hrs | Remaining time without demand before end of season |
| PRODUCTION TO EOL XXXXXX h | Décompteur d'entretien, à 0 h la maintenance est à faire |
| PRODUCTION TO EOL XXXX kg | Maintenance counter, at 0 kg maintenance is due |
| TOTAL RUN TIME XXXXX h | Time meter |
| TOTAL PRODUCTION XXXXX kgs | Produced kg counter |
| POWER CONSUMED XXX kW | Displays electrical power consumption |
| MAX POWER RATE XXX kW | Maximum power |

ELECTROVAP® RTH-HC


5.2 SETUP MENU



| | |
|--|---|
| PROD. LIMITATION XXX % | Adjusting of Steam Production 1 STEP - On / Off: 20 % > Limit > 100 % Other control: 50 % > Limit > 100 % |
| CTRL SIGNAL TYPE XXXX XXX | Control signal configuration: 1 STEP ON/OFF, 4-20mA, 0-5V, 0-10V, 2-10V, DIGITAL CTRL, DIGITAL PROBE |
| SET POINT XX % RH | Display when a RH sensor is used Setting the set point (1 - 99 % Rh) |
| PID SETTINGS P: XX I: XX D: XX | Setting of PID (0 to 50: P - I - D) |
| END OF SEASON DRAIN? XXX | Setting: End Of Season (EOS) Enable or disable of drain system (OFF or ON) |
| EOS TIMER SETTING: XX Hrs | Timeout EOS (1 to 72 hrs) |
| AQUASTAT SETTING XX | Aquastat function keeps water hot during steam production shutdowns |
| AQUASTAT SP XX °F XX °C | Water holding temperature setting during shutdowns 65°C > °C > 95°C or 149 °F > °F > 203°F |
| WATER TYPE USED XXXX XXXX | Water type setting: "TAP WATER", "DI WATER", "PARTIAL DI WATER", "SOFTENED WATER" |
| EOL SETTING XXXXXX KG | End Of Life setting: 100>Kg>20000 |

ELECTROVAP® RTH-HC

5.3 CONTROL SYSTEM MENU




| | |
|---------------------------------------|--|
| K FV DV LV1 X X X X | K: Contactor (0 : no production / 1 : production) FV: Filling Valve, DV: Drain valve (0 : closed / 1 : open) LV: Level (0 : low, filling / 1 : production, filling, 2 : intermittent filling, 3 : high, stop filling) |
| NS HLS CTRL D% X X X X | NS: Network status HLS: High Limit Switch 0: open / 1: closed CTRL: Control Signal D%: Steam demand 0 à 100 |
| TX COM 1 | Communication port TX |
| RX COM 1 | Communication port RX |
| A1: L XXX °C XXX°F X R XXX°C XXX°F | Alarm Status A1 0: no fault/ 1: fault Water temperature for right/left tank (NC displayed if the sensor is not connected) |
| A2 LV VF TIMER X X | Alarm Status A2 0: no fault/ 1: fault LV: Level 0 / 1 / 2 / 3 FV : Filling Valve 0 (closed) / 1 (open) |
| A3 LV FV TIMER X X | Alarm Status A3 0: no fault/ 1: fault LV: Level 0 / 1 / 2 / 3 FV : Filling Valve 0 (closed) / 1 (open) |
| A4: L XXX °C XXX°F X R XXX°C XXX°F | Alarm Status A4 0: no fault/ 1: fault Water temperature for right/left tank (NC displayed if the sensor is not connected) |
| A6 LV DV TIMER X X | Alarm Status A6 0: no fault/ 1: fault LV: Level 0 / 1 / 2 / 3 DV : Drain Valve 0 (closed) / 1 (open) |
| A7: LV D% TIMER X X XXX XXXX | Alarm Status A7 0: no fault/ 1: fault LV: Level 0 / 1 / 2 / 3 D%: Demand % TIMER: Timeout |

ELECTROVAP® RTH-HC

| | | | | | |
|------------|-----------|-----------|--------------|-----------------------------|-------------------------------|
| A8 | LV | FV | TIMER | Alarm Status A8 | 0: no fault/ 1: fault |
| X | X | X | X | LV: Level | 0 / 1 / 2 / 3 |
| | | | | FV : Filling Valve | 0 (fermé) / 1 (ouvert) |
| | | | | TIMER: Timeout | |
| A9 | LV | DV | TIMER | Alarm Status A9 | 0: no fault/ 1: fault |
| X | X | X | X | LV: Niveaux | 0 / 1 / 2 / 3 |
| | | | | VS : Vanne de sortie | 0 (fermé) / 1 (ouvert) |
| | | | | TIMER: Timeout | |
| A10 | LV | FV | TIMER | Alarm Status A10 | 0: no fault/ 1: fault |
| X | X | X | X | LV: Level | 0 / 1 / 2 / 3 |
| | | | | FV : Filling Valve | 0 (fermé) / 1 (ouvert) |
| | | | | TIMER: Timeout | |


ELECTROVAP® RTH-HC

5.4 MENU: HUMIDIFIER CONFIGURATION




How to enter your access code :

- Press key 1, the first cross flashes
- Press the 2 or 3 key to change the number.
- Once you've reached the desired digit of your code, press 1 to confirm; the second cross will flash.
- Proceed in the same way for the following digits, and don't forget to validate your code by pressing 1.



ELECTROVAP® RTH-HC



| | |
|--|--|
| LANGUAGE XXXXXXXX | Values : FRANCAIS , ENGLISH, etc... |
| CHANGE UNIT TYPE RTH HC XXX | Model: RTH HC 8 , 10, etc. ...(see range) |
| CHANGE VOLTAGE XxXXX V | Selection of power heating: 2x200/2x220/2x230/3x200/3x208/3x220/3x230/3x380/3x400/3x415/3x440/3x460/3x480/3x575/3x600/3x690 |
| TOTAL GROUP PROD.: XX KG | For Master / Slave control only: adjusts the total production of the RTH group |
| DRAIN LOGIC xxxxxx | Allows to choose the drain logic (CYCLIC BASED or TIMED BASED) |
| CYCLE DRAIN DURATION: Xxxx | Setting of drain duration in seconds |
| DRAIN FREQUENCY: EVERY XX CYCLES | Frequency of drain system IF TIMED BASED: 1 - 255 min IF CYCLIC BASED: 1 - 10 cycles |
| COOLING TYPE: Xxxxxxx | Type of tank cooling ECO COOLING: Natural cooling FAST COOLING : by adding cold water |
| SELF-CHECKING STATUS XXX | Startup of self-checking system ("YES" or "NO") |
| CALIBRATION FOR CTRL SIGNAL XXXX% | Calibration of control signal (-10% at +10%) |

ELECTROVAP® RTH-HC

| | |
|---|---|
| CALIBRATION FOR T° RIGHT XXXX% | Calibration of the tank temperature sensor (-15% at +15%). For the RTH 2 tanks: right temperature. |
| CALIBRATION FOR T° LEFT XXXX% | Only for RTH with 2 tanks only: Calibration left temperature (-15% at +15%). |
| CURRENT TIME YYYY/MM/DD HH:MM | Setting current time (lost when power is off) "year/Month/day Hour/Minute" |
| MFGR TEST DATE MM / YYYY | Factory testing date "Month, year" (read only) |
| NETWORK UNIT ID XXX | Address unit network 1 < ID < 254 |
| COM SPEED XXXX00 bs | Communication network speed for RS485 2400 < speed < 230400 |
| COM PROTOCOL XXXXXXXX | Network connected: "MODBUS RTU" or "BACNET MS/TP" |

ELECTROVAP® RTH-HC

5.5 MAINTENANCE ALERTS

**M1: CHECKING 50hr
DUE**

This message appears 50 hours after the 1st start-up.
Check that all electrical and hydraulic connections (steam hose, drainage system, water supply, etc.) are tight. The unit is not stopped.

**M2: SERVICE DUE
TO DO**

Means that maintenance must be carried out.
The unit is not stopped.

**M3: SERVICE OVER
DUE: DRAINING**

- This message appears if 100 hours have elapsed between the appearance of message M2 and M3 and no maintenance has been carried out.

**M3: SERVICE OVER
DUE: COOLING**

- The unit is then stopped and follows a procedure:

1. Drain tank
2. Cylinder cooling
3. Ready for maintenance

**M3: SERVICE OVER
DUE: STOP UNIT**

**MANUAL DRAIN
IN PROCESS**

This message is displayed once after pressing the manual drain button. The drain is activated..

**COOLING CYCLE
IN PROCESS**

This means that the manual drain is complete, and you must wait for the tank temperature to go down before servicing..


DO MAINTENANCE

The tank is empty and cooled, maintenance can be done.
See technical manual.



TO RESET THE ABOVE MESSAGES, FOLLOW THIS PROCEDURE:

- Press the manual drain button (4) on the unit.
- Press the down arrow button (3) for at least 5 seconds.



5.6 DEFAULT MESSAGES

A1: TANK TEMP.
OVER-HEAT

Meaning:

The temperature inside the tank is too high: > 110°C. Heating elements no longer fully immersed.

In this case :

When this message appears, the tank is drained, the general fault contact is activated and the unit is then shut down.

Possible causes and solutions:

1. **Poor water supply to the tank.** A block of limescale is blocking the water inlet to the tank. The tank must be cleaned.
2. **Water level sensor malfunction.** Check electrical connection between level switch and main board (see control wiring diagrams). Check float integrity and detector cleanliness.
3. **Faulty temperature sensor or need to recalibrate.** If this message appears when the tank is cold, test the temperature sensor (PT100) and replace if necessary, then contact your agent to recalibrate.
4. **Problem with water quality.** Foam is forming in the tank; increase duration of purges. From the "HUMIDIFER CONFIGURATION" menu, find the "DRAIN LOGIC" menu and activate the "TIMED BASED" mode. Also check softener regeneration times when using softened water.
5. **Electronic problem.** In case of malfunction, replace the main board. Next, check that there is no steam rising or water leaking into the electrical compartment.

ELECTROVAP® RTH-HC

A2: TANK FILLING TOO LONG

Meaning:

The tank is not being filled correctly. The water level is below the low level (maximum filling time before alarm: 20 min).

A3: FILL VAPORIZATION AREA

Meaning:

No filling between low and intermediate level.

A8: PROBLEM RE-FILL ISSUE

Meaning:

No filling between intermediate and high levels.

In this case :

When this message appears, the tank is drained, the general fault contact is activated and the unit is then shut down.

Possible causes and solutions:

1. **Check water supply.** The pressure should be constant, between 2 and 8 bar. If in doubt, install a pressure regulator set at 2 bar on the supply pipe. Also check the condition of the water inlet valve, the electrical connection and the F2 (2A) fuse. Replace the valve and fuse if they are faulty.
2. **Check that condensate is properly drained.** Condensate must be drained off, otherwise it accumulates in the ramp, causing water to splash into the unit and pressure to build up in the tank, preventing the unit from being filled.
3. **Check that the drain valve closes properly.** A piece of limestone can block the valve's flap closure and cause a leak, preventing the unit from being filled correctly.
4. **Electronics.** Replace the main board and check that there is no steam rising or water leaking into the electrical compartment.

ELECTROVAP® RTH-HC

A4: TEMP. SENSOR DISCONNECTED

Meaning:


Temperature sensor is either faulty or disconnected.

In this case :

When this message appears, the general fault contact is activated and the unit is stopped.

Possible causes and solutions:

- 1. Check electrical connections.** The temperature sensor must be connected to the main board to connector X04 terminals 17 (2 red wires) and 16 (white wire). The ground wire is connected to connector X105 on terminal 49.



- 2. Defective temperature sensor.** Disconnect temperature sensor from connector X04. Using a multimeter, measure the ohmic value of the PT100 at ambient temperature, and compare this value with the PT100 ohmic value table.
If the value is different, the sensor is faulty, replace the sensor.
- 3. Electronic problem.** Replace the main board and check that there is no steam rising or water leaking into the electrical compartment.

ELECTROVAP® RTH-HC

A6: HIGH LEVEL BLOCKED

Meaning:

The high level is continuously activated (time to detection: 14 minutes).

In this case :

When this message appears, the general fault contact is activated and the unit is stopped.

Possible causes and solutions:

1. **Problem with level switch.** Check electrical connection between level switch and main board (see control wiring diagrams). Check float integrity and detector cleanliness.
2. **Electronic problem.** Replace the main board and check that there is no steam rising or water leaking into the electrical compartment.

A7: VAPORIZATION TOO LONG

Meaning:

Steam production is insufficient.

In this case:

When this message appears, the general fault contact is activated and the unit is stopped.

Possible causes and solutions:

1. **Incorrect power supply.** Using a voltmeter, check terminals L1, L2 and L3 for power supply voltage (Vac) to the heating resistors. If the power voltages are not correct, check the supply circuit down to each resistor and replace any faulty components.
2. **Continuous water supply.** Check water supply pressure ($2 > P \text{ (bar)} > 8$), replace solenoid filling valve if necessary.
3. **Problem with water level sensor.** Check electrical connection between level switch and main board (see control wiring diagrams). Check float integrity and detector cleanliness.
4. **Electronic problem.** Replace the main board and check that there is no steam rising or water leaking into the electrical compartment.

A9: COMPLETE
DRAIN TOO LONG

Meaning:
Water drainage problem.

In this case :
When this message appears, the general fault contact is activated and the unit is stopped.

Possible causes and solutions:

1. **Drain circuit is clogged.** Press "MANUAL DRAIN" button, and check water flow. Perform the following maintenance: tank (page 58), drain valve (page 59), level sensor (page 60). Also check that there are no obstructions in the drain pipe.
2. **Fuse F3 out of order.** Replace fuse F3, located on main board, and drain valve.
5. **Electronic problem.** Replace the main board and check that there is no steam rising or water leaking into the electrical compartment.

A10-AX : LEVEL
CHECK FAILED

Meaning:
Problem with water level sensor or drain system.


In this case :
When this message appears, the tank is drained, the general fault contact is activated and the unit is then shut down.

Possible causes and solutions:

1. **A float level switch is blocked.** Check and clean water level sensor.
2. **The drain valve is out of order and/or fuse F3 is blown.** Replace fuse F3, located on the main board, and the drain valve.
3. **drain circuit blocked.** Clean drain circuit, tank, drain valve, drain hose, recovery water tank (optional).
4. **electronics problem.** Replace the main board and check that there is no steam or water flowing into the electrical compartment.

ELECTROVAP® RTH-HC

Black screen: Power on/off of display and device after possible overheating



Meaning:

The "Overheating" problem is detected by the high temperature sensor (installed on the tank cover).


In this case :

When this display is off, the control voltage is cut off by the high-temperature detector and the unit is switched off.

Possible causes and solutions:


- 1 **Overheating in the tank has been detected.** Check water level sensor, cables and heating elements. Replace worn float sensor and/or heating element, tank gasket and temperature sensor.

Once the problem has been solved, press the high temperature sensor reset button on the tank lid.



TO RESET THE ABOVE MESSAGES, FOLLOW THIS PROCEDURE:

- Press the manual drain button (4) on the unit.
- Press the down arrow button (3) for at least 5 seconds.



6. MAINTENANCE

6.1 STAINLESS STEEL TANK




Fig. 6-1. Humidifier / stainless steel tank

- Drain the water by pressing the drain button (1). Wait for «DO MAINTENANCE » display.
- Cut the power supply to the power circuits (in the general electrical cabinet) and control circuits located on the side of the unit (2).
- Remove the door and unscrew the clamp (3). Completely disconnect the steam hose and remove it from the unit.
- Untighten clamp (s) and disconnect the water hose from the filling cup (4).
- Disconnect the pressure level hose and uncap the water level tank.
- Unscrew the union junction to disconnect the drain hose.
- Swing the tank down to intermediate position.
- Unlock the 4 locks of the tank.
- Lift the tank lid (7), mind the positioning marks and lay it upside down on the top of the humidifier.
- Release the tank holding steel cord and swing down the tank (5): the limescale deposit falls into a basin or our flexible bag (optional).
- Swing the tank (6) back to its intermediate position.
- Take off the collecting container and swing back the tank in intermediate position. Fasten the tank holding steel chain.
- Grease the tank gasket with silicon grease.
- Put back the tank lid onto the tank body taking care to align the positioning mark. Pay particular attention that no power wires be jammed between the tank and the bottom and gathered them in the insert bundle clip
- Wipe the high-water level floats or electrodes and put the water level detector back. Do not forget to reconnect the pressure level hose. Swing the tank up.
- Reassemble the drain valve in its original position and retighten the collar clamps.
- Tighten up the black knob, reconnect the drain and steam hoses and hang back the doors.

Take care: the tank gasket should be changed whenever the tank is maintained. Retighten all clamps.

Do not scratch harshly, hit or use corrosive liquids on the heating elements.

Very important:

- Do not use solvents to clean the water level detector. If you need to intervene on the detector, do not use special glues but only Teflon.

ELECTROVAP® RTH-HC

➤ **Check that the “T” and the anti-clogging system** of the tank have not been pulled down with the limescale deposit. Otherwise, pick it up from the collecting bag and reinstall it

6.2 DRAIN VALVE

The drain valve must be cleaned each time the steam tank is serviced or changed.

- Once your tank has been removed from the humidifier, disconnect the power cables from the drain solenoid valve (point 3).
- Unscrew clamp (point 1).
- You can now remove the complete valve.
- Wash the filter.
- Check and clean, if necessary, the inside of the valve body by running water through the hole.




Fig. 6-2. Humidifier: drain valve

Reassemble the drain valve as before repositioning the tank, as follows:

1. install the cleaned cover.
2. tilt the tank backwards.
3. Install safety chain and cap nut.
4. Connect drain valve
5. Install the pipes and all hose clamps.


Make sure all hose clamps are tight when servicing the humidifier.

ELECTROVAP® RTH-HC

6.3 WATER INLET VALVE

The water inlet valve should be serviced after the first 50 hours of operation. Thereafter, at least twice a year.

- Switch off the device.
- Turn off the humidifier water supply and unscrew the water supply hose.
- Disconnect the power cables from your humidifier's water inlet valve (Item 1).
- Loosen clamp and remove water supply hose (Item 2).
- Unscrew the two valve fixing screws (Item 3).
- Take out your valve, remove the filter with pliers and remove the coil (Item 4) by levering with a screwdriver.
- Run water through the valve body and filter to remove any particles.




Once all these operations have been completed, reassemble the unit, taking care to check the condition of the water inlet hose clamp. You can now put your appliance back into service.

Every time you have your humidifier serviced, check that the clamps are in good condition and tight.

6.4 WATER LEVEL SENSOR

The level switch must be cleaned at each maintenance visit.

1. Disconnect cables from water level switch (1).
2. Unscrew the pressure-balancing tube clamp (2) and remove it from the cover.
3. To release the detector, unscrew the hose clamp (3) and disconnect the hose. **Caution: there may still be water inside the hose.**
4. Without unscrewing, clean the hose.
5. Unscrew the 3 screws (4) to clean the floats and level switch body.




ELECTROVAP® RTH-HC

7. SPARE PARTS

7.1 STAINLESS STEEL CUVE

| No | Code | Description |
|----|----------------|-----------------------------|
| 1 | D111781-SP | Immersion heater nut M5 |
| 2 | D110830-SP | Immersion heater support |
| 3 | D36282 | Tank gasket |
| 4 | D110754-SP | High-temperature switch |
| 5 | D94057-SP | Probe lead-through |
| 6 | D94058-SP | Temperature sensor |
| 7 | D110765-230-SP | Immersion heater 230V 1900W |
| | D110765-277-SP | Immersion heater 277V 1900W |
| | D110765-346-SP | Immersion heater 346V 1900W |
| | D110765-398-SP | Immersion heater 398V 1900W |
| | D110761-230-SP | Immersion heater 230V 4300W |
| | D110761-277-SP | Immersion heater 277V 4300W |
| | D110761-346-SP | Immersion heater 346V 4300W |
| | D110761-398-SP | Immersion heater 398V 4300W |
| 8 | D110747-SP | "T" water supply |
| 9 | D94061-SP | Anti-clogging system |
| 10 | D110750-SP | Stainless steel bowl |



If the tank is completely changed, use the reference below:

Complete tank Voltage RTH-HC model

↓ ↓ ↓

D110769-3x400-40

Fig. 7-1. Tank

ELECTROVAP® RTH-HC

7.2 WATER INLET SOLENOID VALVE

| N° | Code | Description |
|-----|---------------|-------------------|
| 1-2 | D110771-SP | Water inlet valve |
| 2 | D116645-24 | 24V coil |
| | D116645-24-UL | UL 24V coil |
| 3 | D111775-SP | Valve support |




Fig. 7-2. Water inlet valve

7.3 WATER LEVEL SENSOR

| N° | Code | Description |
|-----------|---------------|------------------------------------|
| 1 - 4 & 6 | D110232-DI-SP | Level switch with float - complete |
| 1 | D108231-SP | Upper part Polypropylene |
| 2 | D108237-SP | Flat gasket for float (set of 3) |
| 3 | D80985-SP | Level sensor (set of 3) |
| 4 | D110734-SP | O-ring seal |
| 5 | D108230-SP | Stainless steel detector holder |
| 6 | D110735-SP | Bottom section Polypropylene |




Fig. 7-3. Water level sensor

7.4 DRAIN SOLENOID VALVE

| N° | Code | Description |
|-------|---------------|--------------------------------|
| 1 - 3 | D127990-SP | Complete Drain solenoid valve. |
| 1 | D108256-SP | Hose clamp |
| 2 | D110205-HC-SP | Filter |
| 3 | D128002-SP | Connector |




Fig. 7-4. Drain solenoid valve

ELECTROVAP® RTH-HC

7.5 ELECTRICAL PART

| N° | Code | Description |
|----|-------------------|---|
| 1 | D110124-SP | Display board |
| 2 | D121388-5-SP | RTH-HC main board (OTI) |
| 3 | D50931-SP | Information return board |
| 4 | D109737-SP | 35mm ² power terminal (L1, L2, L3) |
| 5 | D110168-SP | Control terminal 16mm ² (L, N) |
| 6 | D107491-SP | 2.5mm ² terminal (1, 2, 3, 4) |
| 7 | D110163-SP | 35mm ² earth terminal. |
| 8 | D110806-600-60-SP | Solid-state relay RTH-HC 5 - 15 if Up[v] = 230-600V |
| | D110806-600-90-SP | Solid-state relay RTH-HC 20 - 100 if Up[v] = 230-600V |
| | D110806-690-75-SP | Solid-state relay RTH-HC if Up[v] = 690V |
| 9 | D50932-SP | 24V contactor |
| 10 | D110173-SP | Double terminal 115/230V |
| 11 | D110768-SP | 6mm ² fuse holder |
| 12 | D110166-SP | Stop |
| 13 | D110128-50-SP | Transformer Prim :2x115V Dry :2x12V |
| 14 | D92393-SP | On/off switch |
| | D116631-SP | Fast fuse 2A - 5 x 20 mm (Pack of 10) |
| | D116718-SP | Fast fuse 5A - 5 x 20 mm (Pack of 10) |

| Position | Amp. | Fuse protection |
|----------------|------|----------------------|
| F1 | 2AT | Power contactor coil |
| F2 | 2AT | Inlet valve coil |
| F3 | 2AT | Drain valve coil |
| F4 | 2AT | Electronic boards |
| Din 5 & 6 rail | 2AT | Transformer |
| Din 7 & 8 rail | 5AT | Transformer |




Fig. 7-5. Electrical compartment



185, Boulevard des Frères Rousseau

76550 Offranville - France

www.devatec.com

Export → Tel. +33 (0)2 35 83 06 44

Email : export@devatec.com